



# City of Santa Clarita

**New General Construction Permit**  
**June 15, 2010**



Hall & Foreman, Inc.

# The New Statewide NPDES Permit

Associated with Construction and Land Disturbance Activities



Hall & Foreman, Inc.

# Background and Important Dates

- 1972 CWA and NPDES permit
- 1987 amendments for municipal and industrial storm water discharges
- Nov 16, 1990 USEPA, 5 acre limit for specified categories of industries
- Aug 19, 1999 order no. 99-08-DWQ
- Dec 8, 1999 threshold lowered to 1 acre
- 2005-2006 Blue Ribbon Panel, NEL
- Sep 2, 2009 order no. 2009-0009-DWQ
- June 15, 2010
- July 1, 2010 effective date



# **State Storm Water Permit**

## **Requirements in Both Current & New NPDES Permit**

### **National Pollution Discharge Elimination System Permit**

*The Objectives of the NPDES Permit is to Eliminate Discharges of Sediment & Pollutants from the Construction Site to Storm Drains and Water Bodies of the U.S.*

**“Waters of the United States” means any water, surface or underground, including saline waters, within the boundaries of the United States.**

## **“How”**

### **Both EPA & State Program**


***Implement an Effective Combination of Best Management Practices (BMPs) based on Best Available Technology (BAT) and Best Available Controls (BACs)***



**Hall & Foreman, Inc.**



# SWRCB GCP Structure



# This GCP Recognizes Four Phases

- Grading and Land Development
- Streets and Utilities
- Vertical Construction
- Final Landscaping and Site Stabilization



Hall & Foreman, Inc.

## What is not covered?

- Construction activity that disturbs less than 1 acre of land surface
- Custom Homes
- Routine maintenance within right-of-way
- Landfill subject to Industrial permit
- Storm and Sewer combined discharge



# Significant changes in Implementation

## Requires All Reporting Electronically

- Electronic Submittal via SMART State Platform
- Permit Registration Documents (PRDs)
  - Notice of Intent (NOI)
  - Risk Assessment (Exception for existing sites with current permit)
  - Site Map
  - SWPPP
  - Annual Fee
  - Signed Certification Checklist
- Inspections – Designated Individual





## Summary of Significant Changes

- Risk-Based Permitting Approach
- Technology-Based NAL, 6.5 to 8.5 pH, 250 NTU turbidity
- Technology-Based NEL, 6 to 9 pH, 500 NTU for Risk 3
- Linear Underground/Overhead Projects
- Rain Event Action Plan, REAP, 48 hrs
- Certification/Training Requirements for Key Personnel
- Effluent Monitoring and Reporting



## Summary of Significant Changes continued

- Rainfall Erosivity Waiver,  $R < 5$ , 1 to 5 acre sites
- Project Site Soil Characteristics Monitoring & Reporting
- Minimum Requirements Specified, more BMPs
- Receiving Water Monitoring and Reporting, Risk 3
- Post-Construction Storm Water Performance Standards (exception for LUP projects)
- Annual Reporting



# More Impacts

## Requires Rain Event Action Plan (REAP)

- Risk Levels 2 & 3

## Annual Reporting Requirements

- Submit Electronically

## Required Certification / Training

- SWPPP Preparers, Inspectors, SWPPP Manager

## Advanced Treatment Systems (ATS)

- Detention Basins
- Flocculants
- Outsource Equipment (Baker Tank, etc.)

## Inspections

- Weekly – Year Round
- Once each 24-hour period during extended storm events



# Risk Determination

- Traditional Projects
- Linear Projects



Hall & Foreman, Inc.

# Traditional Projects

- **(1) Project sediment risk**
- **(2) Receiving water risk**
- Project Sediment Risk:
- $A = (R)(K)(LS)(C)(P)$
- Where: A = the rate of sheet and rill erosion R = rainfall-runoff erosivity factor, K = soil erodibility factor, LS = length-slope factor, C = cover factor (erosion controls), P = management operations and support practices (sediment controls)
- R factor for the project is calculated using the online calculator at <http://cfpub.epa.gov/npdes/stormwater/LEW/lewCalculator.cfm>.
- The product of K and LS are mapped
- To determine soil loss in tons per acre, the discharger multiplies the R factor times the value for K times LS from the map.





<http://cfpub.epa.gov/npdes/stormwater/LEW/lewCalculator.cfm>


<http://cfpub.epa.gov/hqdes/stormwater/LEW/lewCalculator.cfm>

570/2040

[http://pub.epa.gov/epaosr/atomwater/LEW/eosivity\\_index\\_result.cfm](http://pub.epa.gov/epaosr/atomwater/LEW/eosivity_index_result.cfm)

5/31/2020

# K\*LS Map



Hall & Foreman, Inc.


| Combined Risk Level Matrix  |      |                      |         |         |
|-----------------------------|------|----------------------|---------|---------|
|                             |      | <u>Sediment Risk</u> |         |         |
|                             |      | Low                  | Medium  | High    |
| <u>Receiving Water Risk</u> | Low  | Level 1              | Level 2 |         |
|                             | High | Level 2              |         | Level 3 |

Project Sediment Risk: **Low**  
 Project RW Risk: **High**  
 Project Combined Risk: **Level 2**





# Receiving Water Risk



# Risk Level Requirements

- Risk level 1 projects are subject to minimum BMPs and visual monitoring requirements, requires Good Housekeeping, Visual Monitoring
- Risk level 2 projects are subject to NALs and some additional monitoring requirements, REAP, and Effluent monitoring
- Risk level 3 projects are subject to NELs, and more rigorous monitoring requirements such as receiving water monitoring and in some cases bioassessment




# Risk Factor Entry Form

| Sediment Risk Factor Worksheet  |   | Entry |
|---|---|-------|
| <b>A) R Factor</b>  |   |       |
| <p>Analyses of data indicated that when factors other than rainfall are held constant, soil loss is directly proportional to a rainfall factor composed of total storm kinetic energy (E) times the maximum 30-min intensity (I30) (Wischmeier and Smith, 1958). The numerical value of R is the average annual sum of EI30 for storm events during a rainfall record of at least 22 years. "Isoerodent" maps were developed based on R values calculated for more than 1000 locations in the Western U.S. Refer to the link below to determine the R factor for the project site.</p> <p><a href="http://cfpub.epa.gov/npdes/stormwater/LFWlewCalculator.cfm">http://cfpub.epa.gov/npdes/stormwater/LFWlewCalculator.cfm</a></p>   |   |       |
| R Factor Value  | 0 |       |
| <b>B) K Factor (weighted average, by area, for all site soils)</b>  |   |       |
| <p>The soil-erodibility factor K represents: (1) susceptibility of soil or surface material to erosion, (2) transportability of the sediment, and (3) the amount and rate of runoff given a particular rainfall input, as measured under a standard condition. Fine-textured soils that are high in clay have low K values (about 0.05 to 0.15) because the particles are resistant to detachment. Coarse-textured soils, such as sandy soils, also have low K values (about 0.05 to 0.2) because of high infiltration resulting in low runoff even though these particles are easily detached. Medium-textured soils, such as a silt loam, have moderate K values (about 0.25 to 0.45) because they are moderately susceptible to particle detachment and they produce runoff at moderate rates. Soils having a high silt content are especially susceptible to erosion and have high K values, which can exceed 0.45 and can be as large as 0.65. Silt-size particles are easily detached and tend to crust, producing high rates and large volumes of runoff. Use Site-specific data must be submitted.</p> <p><a href="#">Site-specific K factor guidance</a></p> |   |       |
| K Factor Value  | 0 |       |
| <b>C) LS Factor (weighted average, by area, for all slopes)</b>   |   |       |
| <p>The effect of topography on erosion is accounted for by the LS factor, which combines the effects of a hillslope-length factor, L, and a hillslope-gradient factor, S. Generally speaking, as hillslope length and/or hillslope gradient increase, soil loss increases. As hillslope length increases, total soil loss and soil loss per unit area increase due to the progressive accumulation of runoff in the downslope direction. As the hillslope gradient increases, the velocity and erosivity of runoff increases. Use the LS table located in separate tab of this spreadsheet to determine LS factors. Estimate the weighted LS for the site prior to construction.</p> <p><a href="#">LS Table</a></p>  |   |       |
| LS Factor Value   | 0 |       |
| Watershed Erosion Estimate (=R <sub>x</sub> K <sub>x</sub> LS) in tons/acre   |   | 0     |
| <b>Site Sediment Risk Factor</b><br>Low Sediment Risk: < 15 tons/acre<br>Medium Sediment Risk: >=15 and <75 tons/acre<br>High Sediment Risk: >= 75 tons/acre  |   | Low   |



Hall & Foreman, Inc.

# Soil Erodibility Factor "K" nomograph



Hall & Foreman, Inc.

# Average Watershed Slope "LS"

| Sheet<br>Flow<br>Length<br>(ft) | Average Watershed Slope (%) |      |      |      |      |      |      |      |      |      |      |       |       |       |       |       |       |       |       |
|---------------------------------|-----------------------------|------|------|------|------|------|------|------|------|------|------|-------|-------|-------|-------|-------|-------|-------|-------|
|                                 | 0.2                         | 0.5  | 1.0  | 2.0  | 3.0  | 4.0  | 5.0  | 6.0  | 8.0  | 10.0 | 12.0 | 14.0  | 16.0  | 20.0  | 25.0  | 30.0  | 40.0  | 50.0  | 60.0  |
| <3                              | 0.05                        | 0.07 | 0.09 | 0.13 | 0.17 | 0.20 | 0.23 | 0.26 | 0.32 | 0.35 | 0.36 | 0.38  | 0.39  | 0.41  | 0.45  | 0.48  | 0.53  | 0.58  | 0.63  |
| 6                               | 0.05                        | 0.07 | 0.09 | 0.13 | 0.17 | 0.20 | 0.23 | 0.26 | 0.32 | 0.37 | 0.41 | 0.45  | 0.49  | 0.56  | 0.64  | 0.72  | 0.85  | 0.97  | 1.07  |
| 9                               | 0.05                        | 0.07 | 0.09 | 0.13 | 0.17 | 0.20 | 0.23 | 0.26 | 0.32 | 0.38 | 0.45 | 0.51  | 0.56  | 0.67  | 0.80  | 0.91  | 1.13  | 1.31  | 1.47  |
| 12                              | 0.05                        | 0.07 | 0.09 | 0.13 | 0.17 | 0.20 | 0.23 | 0.26 | 0.32 | 0.39 | 0.47 | 0.55  | 0.62  | 0.76  | 0.93  | 1.08  | 1.37  | 1.62  | 1.84  |
| 15                              | 0.05                        | 0.07 | 0.09 | 0.13 | 0.17 | 0.20 | 0.23 | 0.26 | 0.32 | 0.40 | 0.49 | 0.58  | 0.67  | 0.84  | 1.04  | 1.24  | 1.59  | 1.91  | 2.19  |
| 25                              | 0.05                        | 0.07 | 0.10 | 0.16 | 0.21 | 0.26 | 0.31 | 0.36 | 0.45 | 0.57 | 0.71 | 0.85  | 0.98  | 1.24  | 1.56  | 1.86  | 2.41  | 2.91  | 3.36  |
| 50                              | 0.05                        | 0.08 | 0.13 | 0.21 | 0.30 | 0.38 | 0.46 | 0.54 | 0.70 | 0.91 | 1.15 | 1.40  | 1.64  | 2.10  | 2.67  | 3.22  | 4.24  | 5.16  | 5.97  |
| 75                              | 0.05                        | 0.08 | 0.14 | 0.25 | 0.36 | 0.47 | 0.58 | 0.69 | 0.91 | 1.20 | 1.54 | 1.87  | 2.21  | 2.86  | 3.67  | 4.44  | 5.89  | 7.20  | 8.37  |
| 100                             | 0.05                        | 0.09 | 0.15 | 0.28 | 0.41 | 0.55 | 0.68 | 0.82 | 1.10 | 1.46 | 1.88 | 2.31  | 2.73  | 3.57  | 4.59  | 5.58  | 7.44  | 9.13  | 10.63 |
| 150                             | 0.05                        | 0.09 | 0.17 | 0.33 | 0.50 | 0.68 | 0.86 | 1.05 | 1.43 | 1.92 | 2.51 | 3.09  | 3.68  | 4.85  | 6.30  | 7.70  | 10.35 | 12.75 | 14.89 |
| 200                             | 0.06                        | 0.10 | 0.18 | 0.37 | 0.57 | 0.79 | 1.02 | 1.25 | 1.72 | 2.34 | 3.07 | 3.81  | 4.56  | 6.04  | 7.88  | 9.67  | 13.07 | 16.16 | 18.92 |
| 250                             | 0.06                        | 0.10 | 0.19 | 0.40 | 0.64 | 0.89 | 1.16 | 1.43 | 1.99 | 2.72 | 3.60 | 4.48  | 5.37  | 7.16  | 9.38  | 11.55 | 15.67 | 19.42 | 22.78 |
| 300                             | 0.06                        | 0.10 | 0.20 | 0.43 | 0.69 | 0.98 | 1.28 | 1.60 | 2.24 | 3.09 | 4.09 | 5.11  | 6.15  | 8.23  | 10.81 | 13.35 | 18.17 | 22.57 | 26.51 |
| 400                             | 0.06                        | 0.11 | 0.22 | 0.48 | 0.80 | 1.14 | 1.51 | 1.90 | 2.70 | 3.75 | 5.01 | 6.30  | 7.60  | 10.24 | 13.53 | 16.77 | 22.95 | 28.60 | 33.67 |
| 600                             | 0.06                        | 0.12 | 0.24 | 0.56 | 0.96 | 1.42 | 1.91 | 2.43 | 3.52 | 4.95 | 6.67 | 8.45  | 10.26 | 13.94 | 18.57 | 23.14 | 31.89 | 39.95 | 47.18 |
| 800                             | 0.06                        | 0.12 | 0.26 | 0.63 | 1.10 | 1.65 | 2.25 | 2.89 | 4.24 | 6.03 | 8.17 | 10.40 | 12.69 | 17.35 | 23.24 | 29.07 | 40.29 | 50.63 | 59.93 |
| 1000                            | 0.06                        | 0.13 | 0.27 | 0.69 | 1.23 | 1.86 | 2.55 | 3.30 | 4.91 | 7.02 | 9.57 | 12.23 | 14.96 | 20.57 | 27.66 | 34.71 | 48.29 | 60.84 | 72.15 |

LS Factors for Construction Sites. Table from Renard et. al., 1997.

# Monitoring Requirements

**Table 5 - Storm Water Effluent Monitoring Requirements by Risk Level**

|              | Frequency   | Effluent Monitoring<br>(Section E, below)   |
|--------------|---|---|
| Risk Level 1 | when applicable   | non-visible pollutant parameters (if applicable)  |
| Risk Level 2 | Minimum of 3 samples per day during qualifying rain event characterizing discharges associated with construction activity from the entire project disturbed area. | pH, turbidity, and non-visible pollutant parameters (if applicable)   |
| Risk Level 3 | Minimum of 3 samples per day during qualifying rain event characterizing discharges associated with construction activity from the entire project disturbed area. | If NEL exceeded: pH, turbidity and suspended sediment concentration (SSC)., Plus non-visible pollutant parameters if applicable |

**Table 4 - Required Monitoring Elements for Risk Levels**

|              | Visual   | Non-visible<br>Pollutant                        | Effluent                                   | Receiving Water   |
|--------------|--|---|--|---|
| Risk Level 1 |  |   | where applicable                           | not required  |
| Risk Level 2 | three types required   |   | pH, turbidity                              | not required  |
| Risk Level 3 | for all Risk Levels:<br>non-storm water,<br>pre-rain and post-rain | As needed for all<br>Risk Levels (see<br>below) | (if NEL exceeded)<br>pH, turbidity and SSC | (if NEL exceeded) pH,<br>turbidity and SSC.<br>Bioassessment for sites<br>30 acres or larger. |







# Linear Projects, "LUP"

- Confirm that the project qualifies as an LUP. See the flow chart.
- Identify which Risk type (1, 2, or 3) is applicable to the project, based on project sediment and receiving water risk.





# LUP Project Type Determination Flowchart



# LUP Combined Risk Level Matrix

|                                 |        | <u>PROJECT SEDIMENT RISK</u> |        |        |
|---------------------------------|--------|------------------------------|--------|--------|
| <u>RECEIVING<br/>WATER RISK</u> |        | LOW                          | MEDIUM | HIGH   |
|                                 | LOW    | Type 1                       | Type 1 | Type 2 |
|                                 | MEDIUM | Type 1                       | Type 2 | Type 3 |
|                                 | HIGH   | Type 2                       | Type 3 | Type 3 |



# LUP Monitoring Requirements

**Table 3. LUP Summary of Monitoring Requirements**

| LUP Type | Visual Inspections |                 |                 |            | Sample Collection     |                 |                               |
|----------|--------------------|-----------------|-----------------|------------|-----------------------|-----------------|-------------------------------|
|          | Daily Site BMP     | Pre-storm Event | Daily Storm BMP | Post Storm | Storm Water Discharge | Receiving Water | Non-Visible (when applicable) |
|          |                    | Baseline        |                 |            |                       |                 |                               |
| 1        | X                  |                 |                 |            |                       |                 | x                             |
| 2        | X                  | X               | X               | X          | X                     |                 | x                             |
| 3        | X                  | X               | X               | X          | X                     | X               | x                             |

**Table 4. LUP Type 2 & 3 Effluent Monitoring Requirements**

| LUP Type | Frequency   | Effluent Monitoring  |
|----------|---|--|
| 2        | Minimum of 3 samples per day characterizing discharges associated with construction activity from the project active areas of construction. | Turbidity, pH, and non-visible pollutant parameters (if applicable)  |
| 3        | Minimum of 3 samples per day characterizing discharges associated with construction activity from the project active areas of construction. | turbidity, pH, suspended sediment concentrations (SSC) <sup>13</sup> (only if turbidity NEL exceeded), plus non-visible pollutant parameters (if applicable) |



## NEL and NAL for Risk Level 2 and 3

| Parameter | Test Method  | Discharge Type | Min. Detection Limit | Units    | Numeric Action Level               | Numeric Effluent Limitation        |
|-----------|--|----------------|----------------------|----------|------------------------------------|------------------------------------|
| pH        | Field test with calibrated portable instrument                   | Risk Level 2   | 0.2                  | pH units | lower NAL = 6.5<br>upper NAL = 8.5 | N/A                                |
|           |  | Risk Level 3   |                      |          | lower NAL = 6.5<br>upper NAL = 8.5 | lower NEL = 6.0<br>upper NEL = 9.0 |
| Turbidity | EPA 0180.1 and/or field test with calibrated portable instrument | Risk Level 2   | 1                    | NTU      | 250 NTU                            | N/A                                |
|           |  | Risk Level 3   |                      |          | 250 NTU                            | 500 NTU                            |



## Reference Websites

- State Water Resource Control Board  
<http://www.waterboard.ca.gov/stormwtr/construction.html>
- Caltrans Construction Sites Runoff Characterization Study, dated September 2002  
<http://www.dot.ca.gov/hq/env/stormwater/pdf/CTSW-RT-02-055.pdf>
- Natural Resources Conservation Service Soil Survey  
<http://www.soils.usda.gov/>
- National Weather Service Forecast Office <http://www.srh.noaa.gov/forecast>
- Erosivity Index <http://ei.tamu.edu>
- CASQA BMP Handbook [www.cabmphandbooks.com](http://www.cabmphandbooks.com)



**Go Lakers !**



# QUESTIONS & THANK YOU

Joe Zucker can be reached by:

Direct Phone: (951) 294-9323

Email: [Jzucker@hfinc.com](mailto:Jzucker@hfinc.com)

Henrik Nazarian

661-284-7415 or cell 818-269-1206

Email: [Hnazarian@hfinc.com](mailto:Hnazarian@hfinc.com)



Hall & Foreman, Inc.